

# CRUSSIS

## Installation instructions for kick scooters series ACTIVE, URBAN, ROAD

### Step 1.



Make sure that carton is not damaged

### Step 2.



Remove the kick scooter out of the box

### Step 3.



Wheels are attached to the frame

### Step 4.



Remove the tape holding front and rear wheel

### Step 5.



Put wheels aside

### Step 6.



Remove the protecting material from frame

### Step 7.



Remove the protecting material from handlebars

### Step 8.



Assembling of the kick scooter is only  
in attaching wheels and handlebars

### Step 9.



Loosen the screws on the stem  
and align so that it faces forward while riding

### Step 10.



In this step set the direction of the stem  
roughly. You will align it precisely  
later with the wheel on

### Step 11.



Tighten the screws on the stem with force 4 NM

### Step 12.



Remove the screws from the front part  
of the stem





Attach the handlebars



Put back the front part of the stem and lightly tighten, adjust the angle of the handlebar and screw it with 4 NM



Put wheels back on



Tighten quick release. Mind the direction of the wheel



Correct position of the quick release axle to the fork after tightening



At the front and rear brake put cable guard into cable bridge




Adjust the boot (gum)



Test the brakes




If the brake is rubbing the rim adjust the position of the brake pad. With tightening the screw distance will increase



Check the slope of the handlebars so it will suit the angle of the brake levers. We recommend setting at 45 degrees



Stem and front wheel must form a single axis. Make sure that stem is properly tightened with force 4 NM



We wish you many happy kilometers on your new kick scooter CRUSSIS!

